


GB



Caddy®

Arc 251i



Instruction manual



DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007

The EMC Directive 2004/108/EC, entering into force 20 July 2007

Type of equipment

Welding power source

Type of designation etc.

Arc 251i from serial number 810 xxx xxxx (2008 w.10)

Arc 251i is a member of the ESAB product family Caddy®

Brand name or trade mark

ESAB

Manufacturer or his authorised representatives established within the EEA:

Name, address, phone, website:

ESAB AB

Lindholmsallén 9

Box 8004, 402 77 GÖTEBORG, Sweden

Phone: +46 31 509 000, Website: www.esab.com

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1, Arc welding equipment – Part 1: Welding power sources

EN 60974-10, Arc welding equipment – Part 10: Electromagnetic compatibility (EMC) requirements

Additional information: Restrictive use, Class A equipment, intended for use in locations other than residential.

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within EEA, that the equipment in question complies with the safety requirements stated above.

Date

2012-07-31

Signature

A handwritten signature in black ink, appearing to read "Flavio Santos". The signature is stylized and somewhat cursive.

Flavio Santos
Clarification

Position

Global Director of Marketing
and Product Portfolio Equipment


1 SAFETY	4
2 INTRODUCTION	6
2.1 Equipment	6
2.2 Control panel A32, A34	6
3 TECHNICAL DATA	7
4 INSTALLATION	8
4.1 Location	8
4.2 Mains supply	8
4.3 Mains power supply	8
4.3.1 Recommended fuse sizes and minimum cable area	8
5 OPERATION	9
5.1 Connections and control devices	9
5.2 Connection of welding and return cable	9
5.3 TIG welding	10
5.4 Overheating protection	10
6 MAINTENANCE	10
6.1 Power source	10
6.2 Welding torch	10
7 FAULT-TRACING	11
8 ORDERING SPARE PARTS	11
DIAGRAM	12
ORDER NUMBER	14
ACCESSORIES	15

1 SAFETY


Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding and cutting
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up.
 - no-one is unprotected when the arc is struck
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts
4. Personal safety equipment
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves.
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
 - Make sure the return cable is connected securely.
 - Work on high voltage equipment may only be carried out by a qualified electrician.
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand.
 - Lubrication and maintenance must not be carried out on the equipment during operation.



WARNING



Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.

ELECTRIC SHOCK - Can kill

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

ARC RAYS - Can injure eyes and burn skin.

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.


NOISE - Excessive noise can damage hearing

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

MALFUNCTION - Call for expert assistance in the event of malfunction.


Read and understand the instruction manual before installing or operating.

PROTECT YOURSELF AND OTHERS!





WARNING


Do not use the power source for thawing frozen pipes.



CAUTION


Read and understand the instruction manual before installing or operating.




CAUTION

This product is solely intended for arc welding.



CAUTION

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.





Dispose of electronic equipment at the recycling facility!
 In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.
 As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.
 For further information contact the nearest ESAB dealer.

ESAB can provide you with all necessary welding protection and accessories.

2 INTRODUCTION

Arc 25li is a welding current power source intended for use with coated electrodes (MMA welding) and TIG welding.

ESAB's accessories for the product can be found on page 15.

2.1 Equipment

The power source is supplied with:

- Instruction manual for the welding power source
- Instruction manual for the control panel
- 3 m return cable
- 3 m welding cable

Instruction manuals in other languages can be downloaded from the website, www.esab.com.

2.2 Control panel A32, A34



Welding process parameters are controlled via the control panel.

See the separate instruction manual for a detailed description of the control panels.

3 TECHNICAL DATA

Arc 251i	
Mains voltage	400 V ± 15%, 3 50/60 Hz
Mains supply	S _{sc min} 3.3 MVA
Primary current	
I _{max} MMA	14 A
I _{max} TIG	10 A
No-load power demand when in the energy-saving mode, 6.5 min. after welding	30 W
Setting range	
MMA	4 - 250 A
TIG	3 - 250 A
Permissible load at MMA	
30 % duty cycle	250 A / 30 V
60 % duty cycle	190 A / 27.6 V
100% duty cycle	150 A / 26 V
Permissible load at TIG	
30 % duty cycle	250 A / 20 V
60 % duty cycle	190 A / 17.6 V
100% duty cycle	150 A / 16 V
Power factor at maximum current	
MMA	0.94
TIG	0.93
Efficiency at maximum current	
MMA	83 %
TIG	79 %
Open-circuit voltage	
without VRD	65 V
with VRD	< 35 V
Operating temperature	-10 to +40° C
Transportation temperature	-20 to +55° C
Continual sound pressure at no-load	<70 db (A)
Dimensions l x w x h	418 x 188 x 208 mm
Weight	10.5 kg
Insulation class transformer	H
Enclosure class	IP 23
Application class	S

Mains supply, S_{sc min}
 Minimum short circuit power on the network in accordance with IEC 61000-3-12

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40° C.

Enclosure class

The IP code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water. Equipment marked IP23 is designed for indoor and outdoor use.

Application class

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

4 INSTALLATION

The installation must be carried out by a professional.

4.1 Location

Place the power source so that its cooling air inlets and outlets are not obstructed.

4.2 Mains supply


Note

Mains supply requirements

High power equipment may, due to the primary current drawn from the mains supply, influence the power quality of the grid. Therefore connection restrictions or requirements regarding the maximum permissible mains impedance or the required minimum supply capacity at the interface point to the public grid may apply for some types of equipment (see technical data). In this case it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.

4.3 Mains power supply

Make sure that the welding power source is connected to the correct supply voltage and that it is protected by the correct fuse rating. A protective earth connection must be made in accordance with regulations.



Rating plate with supply connection data

4.3.1 Recommended fuse sizes and minimum cable area

Arc 251i	
Mains voltage	400V
Mains cable area mm ²	4 G 1.5
Phase current I _{1eff}	8 A
Fuse	
anti-surge	10 A
type C MCB	10 A

NOTE!


The cable area and fuse rating above comply with Swedish regulations. Use the welding power source in accordance with the relevant national regulations.

5 OPERATION

General safety regulations for handling the equipment can be found on page 5 . Read through before you start using the equipment!

5.1 Connections and control devices

- | | | | |
|---|---|---|---|
| 1 | Mains voltage switch | 4 | Connection for remote control unit |
| 2 | Connection (+)
TIG: return cable
MMA: welding cable or return cable | 5 | Control panel,
see separate instruction manual |
| 3 | Connection (-)
TIG: torch
MMA: return cable or welding cable | | |



5.2 Connection of welding and return cable

The power source has two outputs, a positive terminal (+) and a negative terminal (-), for connecting welding and return cables. The output to which the welding cable is connected depends on the type of electrode used. The connecting polarity is stated on the electrode packaging.

Connect the return cable to the other output on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact between the work piece and the output for the return cable on the power source.

5.3 TIG welding

At TIG-welding complete the power source with:

- a TIG torch with gas valve
- an argon gas tube
- an argon gas regulator
- tungsten electrode

5.4 Overheating protection

The welding power source has overheating protection that operates if the temperature becomes too high. When this occurs the welding current is interrupted and a fault code is displayed on the control panel.

The overheating protection resets automatically when the temperature has fallen.

6 MAINTENANCE

Regular maintenance is important for safe, reliable operation.

Only those persons who have appropriate electrical knowledge (authorized personnel) may remove the safety plates.



CAUTION

All guarantee undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the guarantee period.

6.1 Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on:

- the welding process
- arc times
- placement
- the surrounding environment.

It is normally sufficient to blow the power source clean with dry compressed air (reduced pressure) once a year.

Clogged or blocked air inlets and outlets otherwise result in overheating.

6.2 Welding torch

The wear parts should be cleaned and replaced at regular intervals in order to achieve trouble-free welding.

7 FAULT-TRACING

Try these recommended checks and inspections before sending for an authorized service technician.


Type of fault	Corrective action
No arc.	<ul style="list-style-type: none"> • Check that the mains power supply switch is turned on. • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check the mains power supply fuses.
The welding current is interrupted during welding.	<ul style="list-style-type: none"> • Check whether the thermal cut-outs have tripped (a fault code is displayed on the control panel). • Check the mains power supply fuses.
The thermal cut-out trips frequently.	<ul style="list-style-type: none"> • Make sure that you are not exceeding the rated data for the welding power source (i.e. that the unit is not being overloaded). • Check that the welding power source is not clogged with dirt.
Poor welding performance.	<ul style="list-style-type: none"> • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct electrodes are being used.


8 ORDERING SPARE PARTS

Arc 251i is designed and tested in accordance with the international and European standards EN 60974-1 and EN 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.


Diagram





Arc 251i








Order number







Ordering no.	Denomination	Type
0460 300 880	Welding power source	Caddy® Arc 251i, A32
0460 300 881	Welding power source	Caddy® Arc 251i, A34
0459 839 1	Spare parts list	Arc 251i
0460 449	Instruction manual	Control panel Caddy® A32, A34

Instruction manuals and the spare parts list are available on the Internet at www.esab.com

Accessories

	Remote control unit AT1 MMA and TIG: setting of current	0459 491 896
	Remote control unit AT1 CF MMA and TIG: rough and fine setting of current	0459 491 897
	Foot pedal FS002 with 5 m cable	0349 090 886
	Remote cable 12 pole - 8 pole 5 m 10 m 15 m 25 m	0459 552 880 0459 552 881 0459 552 882 0459 552 883
	Welding cable kit Return cable kit	0700 006 902 0700 006 903
	Cable holder	0460 265 002
	Shoulder strap	0460 265 003

	<p>Tig torch TXH 150 4 m 0700 300 539 Tig torch TXH 150 8 m 0700 300 545 Tig torch TXH 200 4 m 0700 300 553 Tig torch TXH 200 8 m 0700 300 556</p>
	<p>Trolley for 5-10 litre gas cylinder 0459 366 885</p>
	<p>Trolley for 20-50 litre gas cylinder 0459 366 886</p>
	<p>Trolley for 20-50 litre gas cylinder 0460 330 880</p>

ESAB subsidiaries and representative offices

Europe

AUSTRIA
ESAB Ges.m.b.H
Vienna-Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM
S.A. ESAB N.V.
Brussels
Tel: +32 2 745 11 00
Fax: +32 2 745 11 28

BULGARIA
ESAB Kft Representative Office
Sofia
Tel/Fax: +359 2 974 42 88

THE CZECH REPUBLIC
ESAB VAMBERK s.r.o.
Vamberk
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK
Aktieselskabet ESAB
Herlev
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND
ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

FRANCE
ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY
ESAB GmbH
Solingen
Tel: +49 212 298 0
Fax: +49 212 298 218

GREAT BRITAIN
ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03

ESAB Automation Ltd
Andover
Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

HUNGARY
ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY
ESAB Saldatura S.p.A.
Bareggio (Mi)
Tel: +39 02 97 96 8.1
Fax: +39 02 97 96 87 01

THE NETHERLANDS
ESAB Nederland B.V.
Amersfoort
Tel: +31 33 422 35 55
Fax: +31 33 422 35 44

NORWAY
AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND
ESAB Sp.zo.o.
Katowice
Tel: +48 32 351 11 00
Fax: +48 32 351 11 20

PORTUGAL
ESAB Lda
Lisbon
Tel: +351 8 310 960
Fax: +351 1 859 1277

ROMANIA
ESAB Romania Trading SRL
Bucharest
Tel: +40 316 900 600
Fax: +40 316 900 601

RUSSIA
LLC ESAB
Moscow
Tel: +7 (495) 663 20 08
Fax: +7 (495) 663 20 09

SLOVAKIA
ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN
ESAB Ibérica S.A.
Alcalá de Henares (MADRID)
Tel: +34 91 878 3600
Fax: +34 91 802 3461

SWEDEN
ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB international AB
Gothenburg
Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND
ESAB AG
Dietikon
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

UKRAINE
ESAB Ukraine LLC
Kiev
Tel: +38 (044) 501 23 24
Fax: +38 (044) 575 21 88

North and South America

ARGENTINA
CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL
ESAB S.A.
Contagem-MG
Tel: +55 31 2191 4333
Fax: +55 31 2191 4440

CANADA
ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 02 20
Fax: +1 905 670 48 79

MEXICO
ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA
ESAB Welding & Cutting Products
Florence, SC
Tel: +1 843 669 44 11
Fax: +1 843 664 57 48

Asia/Pacific

AUSTRALIA
ESAB South Pacific
Archerfield BC QLD 4108
Tel: +61 1300 372 228
Fax: +61 7 3711 2328

CHINA
Shanghai ESAB A/P
Shanghai
Tel: +86 21 2326 3000
Fax: +86 21 6566 6622

INDIA
ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA
P.T. ESABindo Pratama
Jakarta
Tel: +62 21 460 0188
Fax: +62 21 461 2929

JAPAN
ESAB Japan
Tokyo
Tel: +81 45 670 7073
Fax: +81 45 670 7001

MALAYSIA
ESAB (Malaysia) Snd Bhd
USJ
Tel: +603 8023 7835
Fax: +603 8023 0225

SINGAPORE
ESAB Asia/Pacific Pte Ltd
Singapore
Tel: +65 6861 43 22
Fax: +65 6861 31 95

SOUTH KOREA
ESAB SeAH Corporation
Kyungnam
Tel: +82 55 269 8170
Fax: +82 55 289 8864

UNITED ARAB EMIRATES
ESAB Middle East FZE
Dubai
Tel: +971 4 887 21 11
Fax: +971 4 887 22 63

Africa

EGYPT
ESAB Egypt
Dokki-Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

SOUTH AFRICA
ESAB Africa Welding & Cutting Ltd
Durbanvill 7570 - Cape Town
Tel: +27 (0)21 975 8924

Distributors

For addresses and phone numbers to our distributors in other countries, please visit our home page

www.esab.com



www.esab.com

